

#### General Description

Junckers PREFILL is a water-based fillerbase to be mixed with sanding dust from the floor sanding process.

Junckers PREFILL provides a filler-system with quick drying time to be used in combination with water-based priming and floor-finishing products.

Junckers PREFILL is the ultimate water-based solution to filling floors made of wood species sensitive to changes in humidity.

#### Technical Data

<b>Product:</b>	Water-based acrylic filler-base.
<b>Package sizes:</b>	10 litres.
<b>Appearance:</b>	Creamy/milky. When mixed with sanding dust from the sanding, the mixture dries up to the same colour as the wood.
<b>Coverage:</b>	Approx. 20 m <sup>2</sup> per litre depending on the condition of the floor.
<b>Application tool:</b>	Broad full-edged spatula of stainless steel.
<b>Substrate temperature:</b>	Minimum 15°C.
<b>Dilution:</b>	Mix with sanding dust before water is added to adjust the viscosity.
<b>Drying time:</b>	Approx. 45-90 minutes at 20°C and 50% RH.
<b>Cleaning of tools:</b>	Soap and water immediately after use. Alcohol after drying.
<b>Storage:</b>	Protect against frost. Shelf life 1 year in unopened can and stored at 20°C.
<b>Disposal:</b>	Remains of product should dry up in container and then be removed with other industrial waste. Do not allow to enter drains.

### System Recommendations

<b>High traffic areas:</b>	2 coats Junckers PREFILL + 1 coat Junckers PRELAK 8 m <sup>2</sup> /ltr + 2 coats Junckers STRONG 10 m <sup>2</sup> /ltr or similar.
<b>Low traffic areas:</b>	2 coats Junckers PREFILL + 1 coat Junckers PRELAK 8 m <sup>2</sup> /ltr + 1 coat Junckers STRONG 10 m <sup>2</sup> /ltr or similar.
<b>Sport:</b>	2 coats Junckers PREFILL + 1 coat Junckers PRELAK 8 m <sup>2</sup> /ltr + 1 - 2 coats Junckers SPORT High Performance 10 m <sup>2</sup> /ltr

### Directions for Use

#### Untreated/sanded floors

The floor surface should be clean, dry and free from dust, wax, grease, polish etc. The last sanding should be carried out by using minimum a 120 grit sandpaper or screen.

Machine sand the surface to remove dirt and irregularities. Mix enough sanding dust into Junckers PREFILL until a thick but spreadable paste is obtained. If too thick water is used to adjust. Spread the paste quickly using a stainless steel spatula.

Sand with sandpaper grit 100-120. Vacuum thoroughly. the floor is now ready to be sealed.

#### Previously lacquered floors:

Machine sand before applying Junckers PREFILL. Use grit 24 to strip old coats. Then remove abrasion marks with grit 60. Finally, use grit 120-180 to obtain a completely smooth surface. Vacuum sanding dust and fill the floor as described under "Untreated/sanded floors".

### Important!

Before use of the product, read the label on the container carefully and observe the advised precausional safety measures.